

**55" MINI TRAMPOLINE & ENCLOSURE
INSTRUCTION MANUAL**



Read these materials prior to assembling and using this trampoline.

WARNING:

Table of Contents

Liability	1
Initial Warning	1
Assembly and Installation Instructions	2
Care and Maintenance Instructions	2
User Instructions	3
Trampoline Safety and Accident Prevention	4
Owner's and Supervisor's Role in Preventing Injuries & Responsibilities	4
User's Role in Preventing Injuries & Responsibilities	4
Trampoline & Enclosure Assembly	5 - 8
Parts List	9
Limited Warranty	10

Liability

While every attempt is made to embody the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which is representative of the company can waive or change.

WARNING:

In addition to the instructions and precautions provided with your Trampoline, the following precautions must be observed while using the Trampoline Safety Enclosure.

- DO NOT attempt or allow someone else on the Trampoline. Landing on the head or neck can cause serious injury, paralysis, or death, even when landing in the middle of the bed.
 - Do not allow more than one person on the trampoline or inside the trampoline enclosure. Use by more than one person at the same time can result in serious injuries.
 - The metal frame of the trampoline enclosure will conduct electricity. Lights, extension cords, and all such electrical equipment must never be allowed to come in contact with the enclosure.
 - Inspect the enclosure before each use. Make sure the straps and all parts are correctly and securely positioned and attached. Tighten any loose hardware. Replace any worn, defective, or missing parts.
 - Wear comfortable clothing free of hooks, snaps, drawstrings or anything which may snag or catch in the safety enclosure mesh. Remove jewelry, neckties, and earrings.
 - Climb on and off the trampoline only through the safety enclosure entrance and securely close entrance. Users, especially children, must not attempt to enter or exit between the trampoline frame and the enclosure. Doing this may pose a strangulation risk.
 - Do not touch or rebound off the safety enclosure mesh while using the trampoline.
 - Read all instructions and complete all assembly before allowing your child to use the trampoline & safety enclosure.
 - Use trampoline and trampoline enclosure only with mature, knowledgeable adult supervision.
- For Recreational Use ONLY. Not for Professional Use.
Weight Limit for Trampoline & Enclosure User is 100 lb.

Assembly and Installation Instructions

WARNING:

- ADULT ASSEMBLY REQUIRED - Contains small parts, sharp points and sharp edges.
 - CHOKING HAZARD - Small parts - Not for children under 3 yrs.
 - For use by children ages three (3) to six (6) ONLY.
 - Maximum user weight is 100 lbs.
 - Adequate overhead clearance is essential. A minimum of 8 ft. from ground level is recommended. Provide clearance for wires, tree limbs, and other possible hazards.
 - Lateral clearance is essential. Place the trampoline and trampoline enclosure away from walls, structures, fences, and other play areas. Maintain a clear space on all sides of the trampoline and trampoline enclosure. A minimum of six feet from frame edge is recommended.
 - Never set-up the trampoline in heavy rain, wind or storm conditions, especially lightning storms. It is recommended that the trampoline be taken apart and stored in bad weather.
 - Place the trampoline and trampoline enclosure on a level surface before use.
 - Secure the trampoline and trampoline enclosure against unauthorized and unsupervised use.
 - Remove any obstructions from beneath the trampoline and trampoline enclosure prior to use.
 - The owner and supervisors of the trampoline and trampoline enclosure are responsible to make all users aware of practices specified in the "Use Instructions".
- Inspect the trampoline and trampoline enclosure before each use and replace any worn, defective, or missing parts.
- The following conditions could represent potential hazards:
1. Missing, improperly positioned, or insecurely attached frame padding, barrier or enclosure support system (frame) padding and pole caps.
 2. Punctures, frays, tears, or holes worn in the bed or frame padding, barrier or enclosure support system (frame) padding and pole caps.
 3. Deterioration in the stitching or fabric of the bed or frame padding, barrier or enclosure support system (frame) padding and pole caps.
 4. Ruptured suspension cords.
 5. A bent or broken frame or support system.
 6. A sagging barrier or bed.
 7. Sharp protrusions on the frame or suspension system, or
 8. Loosened or missing hardware. Always make sure hardware is tight before each use.

Care and Maintenance Instructions

WARNING:



WARNING: Use Instructions

- **DO NOT attempt or allow somersaults on the Trampoline.** Landing on the head or neck can cause serious injury, paralysis, or death, even when landing in the middle of the bed.
- Do not allow more than one person on the trampoline or inside the trampoline enclosure. Use by more than one person at the same time can result in serious injuries.
- Keep objects away which could interfere with the performer. Maintain a clear area around the trampoline. Do not allow foreign objects or animals on the trampoline.
- Children should only use trampoline and trampoline enclosure with mature, knowledgeable adult supervision.
- Trampoline is for use by children ages three (3) to six (6).
- The trampoline should be assembled in its entirety before each use. All suspension cords must be attached to the frame. The frame cover must be correctly positioned at all times.
- Never set up the trampoline in heavy rain, wind or storm conditions, especially lightning storms. It is recommended that the trampoline be taken apart and stored in bad weather.
- Inspect the trampoline & enclosure before each use. Make sure the frame cover, barrier mesh, and enclosure support padding are correctly and securely positioned. Replace any worn, defective or missing parts.
- The metal frame of the trampoline and trampoline enclosure will conduct electricity. Lights, extension cords, and all such electrical equipment must never be allowed to come in contact with the trampoline or trampoline enclosure.
- Wear comfortable clothing. Remove jewelry, neckties, and earrings. Wear clothing free of drawstrings, hoods, hoppers or anything that could get caught in the barrier mesh.
- Enter and exit the enclosure only at the enclosure door or barrier opening designated for that purpose. It is dangerous practice to jump from the trampoline to the ground or floor when dismounting, or to jump onto the trampoline when mounting. Do not use the trampoline as a springboard to other objects.
- Stop bounce by flexing knees as feet come in contact with the trampoline bed. Learn this skill before attempting others.
- Avoid bouncing too high. Stay low until bounce control and repeated landing in the center of the trampoline can be accomplished. Control is more important than height.
- While keeping the head erect, focus eyes on the trampoline toward the perimeter. This will help control bounce.
- Avoid bouncing when tired. Keep turns short.
- Properly secure the trampoline when not in use. Protect it against unauthorized use.
- The adult supervisor must not be under the influence of alcohol or drugs.
- For additional information concerning the trampoline equipment, contact the manufacturer.
- For information concerning skill training, contact a certified trampoline instructor.
- Bounce only when the surface of the bed is dry. Wind or air movement should be calm to gentle. The trampoline must not be used in gusty or severe winds. The trampoline should be taken apart or stored indoors during these types of weather conditions.
- Read all instructions before using the trampoline and trampoline enclosure. Warnings and instructions for care, maintenance, and use of this trampoline and trampoline enclosure are included to promote safe, enjoyable use of this equipment.
- Do not intentionally bounce off the barrier.
- Do not attempt to jump over barrier or attempt to crawl under barrier.
- Do not hang from, kick, cut or climb on barrier.
- Do not attach anything to the barrier that is not a manufacturer approved accessory or part of the enclosure system.

Trampoline Safety and Accident Prevention

As in most recreational sport, participants may be injured. This section covers the most common accidents. Responsibilities of the supervisors and jumpers in accident prevention are also outlined.

The following are reasons why accidents happen:

- Attempting somersaults. Landing on the head or neck can cause serious injury, paralysis, or death, even when landing in the middle of the bed.
- More than one person on the trampoline. Use by more than one person at the same time can result in serious injuries.
- Incorrect mounting and dismounting. Carefully crawl out of and into the trampoline bed. Do not jump off to the ground. Do not jump from a roof, or other object onto the trampoline. Small children may need assistance to get on or off the trampoline. Do not step onto the suspension system.
- Hitting the frame. Stay in the center of the trampoline when jumping. Injury may result from hitting the frame when control is lost. Be sure the frame cover is always on and the pads securely fastened. Do not jump directly onto the frame pad.
- Loss of control. A jumper who loses control will increase his/her chance of injury. Be sure to familiarize yourself with the basic jumps before doing more difficult ones. Jumps should be mastered, performed repeatedly before moving on to the next level. To regain control and stop your jump, bend your knees sharply as you land.
- The adult supervisor must not be under the influence of alcohol or drugs.
- Foreign objects. Please make sure there is nothing sharp under and around the trampoline. Hitting objects under the trampoline can cause injury. Jumping with a foreign object can also increase the chances of getting injured. Be sure there is adequate clearance 8 feet above and 6 feet around the trampoline. Be careful of overhead wires, tree limbs etc.
- Bad weather. Do not use your trampoline in gusty winds or inclement weather. The bed should not be wet.
- Poor maintenance of the trampoline. Make sure you inspect the trampoline before every use. Check for punctures on the bed, sharp burrs on the frame, stitching that has gone bad or loose elastic bands. If a replacement part is needed, please call our hotline to order.
- Unlimited access. The trampoline should be covered or disassembled when not in use. This will prevent unsupervised small children from using the trampoline.

Owners & Supervisors Role in Preventing Injuries & Responsibilities

The supervisor's role is to make sure the users know all the safety rules as well as learn the basic fundamental bounces. They need to enforce all the safety rules and warnings in the manual, frame and labels. When a supervisor is not available, the trampoline may be dis-assembled or covered to limit access. It is the supervisor's responsibility that the placards with the Trampoline Safety Tips and Enclosure Safety tips are reviewed and all jumpers are informed about the tips.

User's Role in Preventing Injuries & Responsibilities

The jumper must first learn all of the basic, fundamental bounces before attempting more difficult ones. Low, controlled bounces are a good start before learning the basic landing positions and combinations. Jumpers need to understand that control is key to a successful jump. Following the tips in the placard is important. Contact a certified trampoline instructor for more information.

TRAMPOLINE & ENCLOSURE ASSEMBLY

Refer to PARTS LIST for identification of parts.

⚠ WARNING:
CHOKING HAZARD - Small Parts
Not for children under 3 yrs.

⚠ WARNING:
ADULT ASSEMBLY REQUIRED
Contains small parts, sharp points and sharp edges.



1. Begin by assembling 2 of the top rails together into an arc.




2. Continue building a circle by adding the remaining 4 top rails to the arc you made in Step 1.



3. Joining the 2 loose ends of the circle together may require you to stand the frame on edge and press downward on the 2 ends, while connecting them together.



4. Align the screw hole in the leg with the hole in the leg socket. Then secure with screw tightly. Do not over-tighten. Repeat this until all 6 legs are securely attached to the top rail frame with screws.



5. After attaching all 6 legs securely to the top rail frame, turn the frame over so that the legs point downward.

TRAMPOLINE & ENCLOSURE ASSEMBLY

Refer to PARTS LIST for identification of parts.

⚠ WARNING:
CHOKING HAZARD - Small Parts
Not for children under 3 yrs.


⚠ WARNING:
ADULT ASSEMBLY REQUIRED
Contains small parts, sharp points and sharp edges.




6. Lay out the jump mat in the center of the frame with the elastic rope(A).




6 (B)



6 (C)



7. fix 6 elastic ropes in diagonal.



8. fix other elastic ropes one by one.

TRAMPOLINE & ENCLOSURE ASSEMBLY

Refer to PARTS LIST for identification of parts.

WARNING:
CHOKING HAZARD - Small Parts
Not for children under 3 yrs.

WARNING:
ADULT ASSEMBLY REQUIRED
Contains small parts, sharp points and sharp edges.



9. Install the pad cover.



10. Align the grommet attached to the bottom of the lower mesh skirt with the hole near the base of the leg and secure with screw.



11. Insert the bottom pole and tighten with screws.



12. Insert the top pole and tighten with screws.



12. Insert the EPE

TRAMPOLINE & ENCLOSURE ASSEMBLY

Refer to PARTS LIST for identification of parts.

WARNING:
CHOKING HAZARD - Small Parts
Not for children under 3 yrs.

WARNING:
ADULT ASSEMBLY REQUIRED
Contains small parts, sharp points and sharp edges.



14. Finish Step 13



15. Fix the enclosure



16. Screw up the screw



16. Screw up the screw

All accessories

TRAMPOLINE & ENCLOSURE ASSEMBLY

Refer to PARTS LIST for identification of parts

⚠️ WARNING: TRAMPOLINE & ENCLOSURE ASSEMBLY

Refer to PARTS LIST for identification of parts
 Not for children under 3 yrs. Contains small parts, sharp points and sharp edges.

⚠️ **WARNING:** CHOKING HAZARD - Small Parts
 Not for children under 3 yrs.

⚠️ **WARNING:** ADULT ASSEMBLY REQUIRED
 Contains small parts, sharp points and sharp edges.



⚠️ **WARNING:**

Always read and follow the safety instructions included in this manual and on the signs

⚠️ **WARNING:**

Always read and follow the safety instructions included in this manual and on the signs attached to the trampoline & enclosure.
 Always make sure the entrance door is zipped completely closed before allowing your child to begin jumping.

PARTS LIST


PARTS	QTY.	ITEM
Frame Cover / Skirt	1	A
JUMP MAT/Safety Net /Tied rope	1	B
Suspension Cords	30	C
Screw	30	D
Screw Driver	1	E
Top Rail	6	F
Lower Enclosure Pole	6	G
Upper Enclosure Pole	6	H
Plain(lower)Foam Tube	6	I
Embossed(upper)Foam Tube	6	J
Leg Tube	6	K



A Frame Cover with Sewn-on Skirt Mesh(1)



B JUMP MAT/Safety Net /Tied rope



K Leg Tube

J Embossed(upper)Foam Tube

I Plain(lower)Foam Tube

H Upper Enclosure Pole

G Lower Enclosure Pole

F Top Rail



C Suspension Cord



E Screw Driver

D Screw

LIMITED WARRANTY

DO NOT RETURN TO PLACE OF PURCHASE

Subject to the following limitations, in addition to any imposed by virtue of applicable law, Bravo Sports warrants this Variflex, UltraFlex or AirZone trampoline and/or safety enclosure to be free from defects in materials and workmanship under normal use and service conditions. The tubular steel frame is warranted for two (2) years after the date of purchase. All other parts are warranted for ninety (90) days after the date of purchase. This warranty is limited to the repair and/or replacement of defective parts only. All requests for missing parts must be pre-authorized by calling customer service within 30 days of the date of purchase and must be accompanied by an original receipt from an authorized dealer.

1. This Limited Warranty will apply only if the part(s) are returned freight pre-paid to the Customer Service Department listed below and are accompanied by both an original receipt from an authorized dealer and the Serial Number found on the frame or instruction manual, and if BravoSports, at its sole discretion, determines it (them) to be defective.
2. This Limited Warranty will apply only to Variflex, UltraFlex or AirZone trampolines and/or enclosures that are purchased from an authorized dealer. This Limited Warranty is extended only to the original consumer purchaser and is not transferable.
3. Be sure to retain your original purchase sales receipt and instruction manual for any warranty claim. The instruction manual has a Serial Number on the front cover (a duplicate of which is also found on one of the tubular steel components) that is required for all missing parts and warranty claims. All warranty claims must be accompanied by the original purchase receipt from an authorized dealer and this serial number.
4. Before returning any parts to Bravo Sports for warranty inspection, the original consumer purchaser must obtain an RMA # (Return Merchandise Authorization number) from BravoSports. Such authorization can be obtained by calling our Customer Service Dept. at the toll-free number listed below or by writing to the BravoSports Customer Service Department at the address listed below. The original consumer purchaser is responsible for all shipping costs.
5. Upon receipt of authorization from our Customer Service Department, you must submit your warranty claim to the address below, ship parts freight pre-paid, accompanied by the original, dated purchase receipt with the Serial # from the manual or frame written on it. Do not return this product to the place of purchase. For warranty service, or for missing or replacement parts or any other problems, call or write to our Customer Service Department at the phone number or address listed below. We will send any replacement parts via U.P.S. Ground.
6. This Limited Warranty does not cover damage or loss from wind, rain, fire, snow, ice, or other forces of nature, accident, normal wear, improper assembly, disassembling, or adjustment during set-up or take-down, or any abuse, neglect or misuse of this trampoline, enclosure and/or its parts. Any alteration to the original product voids this warranty.
7. To the extent allowed by applicable law, any implied warranty of merchantability or fitness applicable to this Variflex / AirZone Trampoline and/or Enclosure is limited to the duration of this Limited Warranty. Bravo Sports does not warrant against, and in no event shall Bravo Sports or its authorized agents be liable for, any personal loss, injury, or direct or indirect incidental or consequential damage resulting from the use of this product. Please note that some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This Limited Warranty gives you specific legal rights and you may have other rights which vary from state to state.

This Limited Warranty is null and void if the "Care and Maintenance" instructions on page 2 and the "Use Instructions" on page 3 of this Manual are not followed prior to each use of the trampoline.