


C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.1/16




FOR C007J/C007JD/C858J/C858JD

★适用于UTP/CR/CX, UTQ/CR/CX, UTR/CR/CX, UTS/CR/CX车型

10/12/19

C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.2/16




FOR C007J/C007JD/C858J/C858JD

FOR H牌馬達
 FOR P牌馬達

10/07/01

C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.3/16

A
B
C
D
E



USE FOR C007J

MJ37-A


- SM511
- NM511
- MJ37
- SM432*2

USE FOR C007JD


MJ137-E

- SM513
- NM511
- MJ137
- SM432*2

C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.4/16




C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.5/16





CRL-J 系列

CRA-J 系列



C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.6/16




FOR C007J/C007JD/C858J/C858JD

FOR 牌馬達 (HVP-20)

10/07/01

C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.7/16



- UT103E
- ▣ UT103P

TO SAFETY S.W

TO SYNCHRONIZER

UT54J-2

SK392

JA025

JA014

UT54J

AP604

C

JA062

JA062

JA062

AP434

AP437

JA018

JA021

AP435

JA018

JA021

AP433

AP432

JA021

AP436

JA021

JA042

- UT950
- ▣ UT950P

SM432

SM3051

UT549

CP101

UT523F

- 1 LIFT PRESSER FOOT
- 2 LOOP TRIMMER
- 3 TOP CUTTER (WIPER)

FOR C007JD/C858JD

- FOR H牌馬達 (HVP-70)
- ▣ FOR P牌馬達

10/07/01

C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.8/16


A

B

C

D

E



C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.9/16


A

B

C

D

E



- TXXXXX-A
- TXXXXX-A


FOR C007JD/C858JD

- FOR H牌馬達 (HVP-70)
- FOR P牌馬達


10/07/01

C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.10/16

A
B
C
D
E




C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.11/16




C007JD PARTS LIST FOR UTQ-J GROUP P.12/16

FOR LEFT SIDE




C007JD PARTS LIST FOR UTP-J GROUP P.13/16

A
B
C
D
E




C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.14/16

A
B
C
D
E



C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.15/16




1 FOR F007JD/C007JD/F858JD/C858JD


3 FOR H牌馬達 (HVP-70)

10/07/01


C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.16/16



C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.1/11



C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.2/11



FOR C007J/C007JD/C858J/C858JD

□ FOR H牌馬達
 ▣ FOR P牌馬達

10/07/01


C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.3/11

FOR UTR/WP/UTX


FOR UTS/UTY

A

UT776/WP19




UT218J



TO WIPER

UT226D
WP22(WP)



B

*SM630

*CP112

UT534

TO UNDER TRIMMER

C

TO MAIN POWER

UT103E

TO SAFETY S.W

TO SYNCHRONIZER

D


TXXXXX

T999


TO PRESSER FOOT

E

UT230-E
FOR CL USE



UT810-A1



1

2

3

4

5

FOR C007JD/C858JD/S007KD

FOR H牌馬達 (HVP-20)


*USE FOR UTR

C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.3/8


FOR UTR/WP/UTX

FOR UTS/UTY

UT763 /WP19



UT218J



UT226D
 UT226P
 WP22(WP)

TO WIPER

*SM630


*CP112

UT534


TO UNDER TRIMMER

TO PRESSER FOOT

UT230-E
FOR CL USE



UT810-A1
 UT810P-A



FOR C007JD/C858JD/S007KD

*USE FOR UTR

FOR H牌馬達 (HVP-70)


FOR P牌馬達

C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.4/11


FOR UTR/WP/UTX

FOR UTS/UTY

UT776 /WP19



UT218J



UT226D
 UT226P
 WP22(WP)

TO WIPER

*SM630


*CP112

UT534


TO UNDER TRIMMER

TO PRESSER FOOT

UT230-E
FOR CL USE



UT810-A1
 UT810P-A



FOR C007JD/C858JD/S007KD

*USE FOR UTR

FOR H牌馬達 (HVP-70)

FOR P牌馬達

C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.5/11


A

B

C

D

E



USE FOR C007J

MJ37-A

SM511

NM511

MJ37

SM432*2

(A)

USE FOR C007JD

MJ137-E

SM513

NM511

MJ137

SM432*2

(A)

1

2

3

4


5

☐ FOR H牌馬達

*USE FOR C007JD/C858JD


10/12/19

C007JDPARTS LIST FOR UTR-J(UTS-J) GROUP P.6/11



C007JD PARTS LIST FOR UTS—J GROUP P.7/11


A



B


UTS系列

C




D

E



C007JD PARTS LIST FOR UTR-J GROUP P.8/11

A
B
C
D
E



SM630 CP112

UT776-A SM410*2

WM400*2

UT776

WM400*2

SM435*2

UT771

UT773

UT772

WM400*2

WM110*2

SM135*2

UT759

SM035B*2

UT762

UT761

WM810

UT760K

NM810

SM035B*2

OR040

WM40D

SM301

NM410

NM410

NM410

UT774

UT774-A

NM410

UT758K

SM337B*2

C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.9/11


A

B

C

D

E




1 FOR F007JD/C007JD/F858JD/C858JD

2 FOR H牌馬達 (HVP-20)

3 4 5 10/12/19


C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.10/11



1 FOR F007JD/C007JD/F858JD/C858JD

2 3 4 5
 □ FOR H牌馬達 (HVP-70)

C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.11/11



1 FOR F007JD/C007JD/F858JD/C858JD

2 FOR P牌馬達