



Item No.	Part No.	Description	HP-AP	HP-BP	HP-SBP	HP-CP	HP-BC1P
1	98531030	Needle Cap	•	•	•		
1	98532030	Needle Cap				•	•
2	98530020	Nozzle Cap	•	•	•		
2	98532020	Nozzle Cap				•	•
4	98531430	Nozzle	•	•	•		
4	98535440	Nozzle				•	•
6	98012600	Head O Ring (G901)•	•	•	•	•	•
7	98535530	Body	•				
7	98530504	Body		•			
7	98532540	Body			•		
7	98531540	Body				•	
7	98533540	Body					•
9	98532430	Needle Packing Screw	•	•	•		

Item No.	Part No.	Description	HP-AP	HP-BP	HP-SBP	HP-CP	HP-BC1P
9	98535400	Needle Packing Screw				•	•
10	93906830	Packing-Piston Guide	•	•	•	•	•
11	98532140	Valve Piston	•	•	•	•	
12	98534280	Air Valve Set	•	•	•		
12	98532260	Air Valve Set				•	•
17	98532070	Main Lever	•	•	•		
17	98532240	Main Lever				•	
17	98535020	Main Lever					•
19	98533430	Needle Chucking Guide	•	•	•		
19	98530410	Needle Chucking Guide				•	•
21	98531060	Needle Spring	•	•	•		
21	98532120	Needle Spring				•	•
22	98530550	Spring Guide	•	•	•		
22	98531410	Spring Guide				•	•
23	98530030	Fluid Needle	•	•	•		
23	98532040	Fluid Needle				•	•
24	98531080	Needle Screw	•	•	•	•	•
25	98531550	Pre-Set Cap Set	•	•	•		
25	98534430	Pre-Set Cap Set				•	•
25-1	98532550	Pre-Set Cap	•	•	•		
25-1	98535430	Pre-Set Cap				•	•
25-2	98531460	Pre-Set Handle	•	•	•	•	•
28	98535390	Lid for Cup				•	
29	HPA-SB1	Side Bottle			•		
30	98534010	Blanking Cover			•		
31	98901020	Bottle Set with Lid					•
31-1	98534040	Tube W/Pipe					•
31-2	98534000	Joint					•
31-3	98532310	Bottle Lid					•
31-4	98536000	Lid Packing					•
31-5	98537000	Washer					•
31-6	98538000	Nut					•
31-7	98532330	Bottle without Lid					•